

```
clear all; close all; clc;
% Task 1: Generate eye diagrams for baseband 2-PAM signaling with different pulse shaping fil
ters
N = 1000;
                            % Number of bits transmitted
SampleFreq = 10;
                            % Sampling frequency in Hz
BinarySeq = -SampleFreq:1/SampleFreq:SampleFreq; % Binary sequence
% Task 1: Generate an impulse train representing BPSK symbols
bpsk symbols = 2*(rand(1,N)>0.5)-1;
SymbolIndex = 0:1/SampleFreq:99/SampleFreq;
stem(bpsk symbols(1:100), 'LineWidth', 1.5);
xlabel('Symbol Index');
ylabel('Amplitude');
title('Impulse Train - BPSK Symbols');
axis([0 10 -1.2 1.2]);
grid on;
% Task 1: Generate eye diagrams for different pulse shaping filters
% Sinc Pulse Shape
Sinc Num = sin(pi*BinarySeq); % numerator of the sinc function
Sinc Den = (pi*BinarySeq); % denominator of the sinc function
Sinc DenZero = find(abs(Sinc Den) < 10^-10); % Finding the t=0 position
Sinc Filt = Sinc Num./Sinc Den;
Sinc Filt(Sinc DenZero) = 1; % Defining the t=0 value
figure;
plot(BinarySeq, Sinc Filt);
title('Sinc Pulse shape');
xlabel('Symbol Index');
ylabel('Amplitude');
axis([-SampleFreq SampleFreq -0.5 1.2]);
grid on;
% Raised Cosine Pulse Shape
% roll-off = 0.5
roll off = 0.5;
cos Num = cos(roll off*pi*BinarySeq);
cos_Den = (1 - (2 * roll_off * BinarySeq).^2);
cos DenZero = abs(cos Den) < 10^-10;
RaisedCosine = cos Num./cos Den;
RaisedCosine(cos DenZero) = pi/4;
RC_gamma5 = Sinc_Filt.*RaisedCosine; % Getting the complete raised cosine pulse
figure;
plot(BinarySeq, RC gamma5);
title('Raised Cosine Pulse shape gamma = 0.5');
xlabel('Symbol Index');
ylabel('Amplitude');
axis([-SampleFreq SampleFreq -0.5 1.2]);
grid on;
% roll-off = 1
roll off = 1;
```


```
cos Num = cos(roll off * pi * BinarySeq);
cos Den = (1 - (2 * roll off * BinarySeq).^2);
cos DenZero = find(abs(cos Den) < 10^-20);
RaisedCosine = cos Num./cos Den;
RaisedCosine(cos DenZero) = pi/4;
RC gamma1 = Sinc Filt.*RaisedCosine; % Getting the complete raised cosine pulse
figure;
plot(BinarySeq, RC gamma1);
title('Raised Cosine Pulse shape gamma = 1');
xlabel('Symbol Index');
ylabel('Amplitude');
axis([-SampleFreq SampleFreq -0.5 1.2]);
grid on;
% Task 1: upsampling the transmit sequence
% Without Noise
BPSK Upsample = [bpsk symbols; zeros(SampleFreq-1, length(bpsk symbols))]; % Upsampling the B
PSK to match the sampling frequency
BPSK U = BPSK Upsample(:).';
figure;
stem(SymbolIndex, BPSK U(1:100));
xlabel('Time');
ylabel('Amplitude');
title ('Impulse Train -Upsampled BPSK');
axis([0 10 -1.2 1.2]);
grid on;
% Task 1: Generate eye diagrams for different pulse shaping filters
% Without Noise
Conv sincpulse = conv(BPSK U, Sinc Filt);
Conv RCgamma5 = conv(BPSK U, RC gamma5);
Conv RCgamma1 = conv(BPSK U, RC gamma1);
% Task 1: Taking only the first 10000 samples
% Without noise
Conv sincpulse = Conv sincpulse(1:10000);
Conv RCgamma5 = Conv RCgamma5(1:10000);
Conv_RCgamma1 = Conv_RCgamma1(1:10000);
% Task 1: Reshaping the sequences to build Eye Diagrams
% Without Noise
Conv sincpulse reshape = reshape(Conv sincpulse, SampleFreq*2, N*SampleFreq/20).';
Conv RCgamma5 reshape = reshape(Conv RCgamma5, SampleFreq*2, N*SampleFreq/20).';
Conv RCgamma1 reshape = reshape(Conv RCgamma1, SampleFreq*2, N*SampleFreq/20).';
% Task 1: Plotting the Eye Diagrams
% Without Noise
figure;
plot(0:1/SampleFreq:1.99, real(Conv sincpulse reshape).', 'b');
title('Eye Diagram - sinc pulse');
xlabel('Symbol Index');
ylabel('Amplitude');
axis([0 2 -2.4 2.2]);
grid on;
figure;
```


```
plot(0:1/SampleFreq:1.99, Conv RCgamma5 reshape.', 'b');
title('Eye Diagram - Raised Cosine (roll-off=0.5)');
xlabel('Symbol Index');
ylabel('Amplitude');
axis([0 2 -2.5 2.5]);
grid on;
figure;
plot(0:1/SampleFreq:1.99, Conv RCgamma1 reshape.', 'b');
title('Eye Diagram - Raised Cosine (roll-off=1)');
xlabel('Symbol Index');
ylabel('Amplitude');
axis([0 2 -1.5 1.5]);
grid on;
% Task 2: Repeat Task 1 in the presence of additive white Gaussian noise (AWGN)
SNR dB = 10;
NoisePower = 1./(10.^{(0.1*SNR dB)}); % Noise Power (Eb = 1 in BPSK)
% Noise Array Generation based on SNR = 10dB
Noise1D = normrnd(0, sqrt(NoisePower/2), [1, N]);
AWGN TX = bpsk symbols + Noise1D;
figure;
stem(SymbolIndex, AWGN TX(1:100));
xlabel('Time');
ylabel('Amplitude');
title('Impulse Train - BPSK Symbols with Noise');
axis([0 10 -1.5 1.5]);
grid on;
% Task 1: Reshaping the sequences to build Eye Diagrams
% Without Noise
Conv sincpulse reshape = reshape(Conv sincpulse, SampleFreq*2, N*SampleFreq/20).';
Conv RCgamma5 reshape = reshape(Conv RCgamma5, SampleFreq*2, N*SampleFreq/20).';
Conv RCgamma1 reshape = reshape(Conv RCgamma1, SampleFreq*2, N*SampleFreq/20).';
% Task 2: upsampling the transmit sequence
% With Noise
AWGNTx Upsample = [AWGN TX; zeros(SampleFreq-1, length(bpsk symbols))];
AWGNTx U = AWGNTx Upsample(:);
figure;
stem(SymbolIndex, AWGNTx U(1:100));
xlabel('Time');
ylabel('Amplitude');
title('Impulse Train - Upsampled BPSK with noise');
axis([0 10 -1.5 1.5]);
grid on;
% Task 2: Generate eye diagrams for different pulse shaping filters
% With Noise
Conv sinchoise = conv(AWGNTx U, Sinc Filt);
Conv RC5noise = conv(AWGNTx U, RC gamma5);
Conv R1noise = conv(AWGNTx U, RC gamma1);
% Task 2: Taking only the first 10000 samples
```


```
% With noise
Conv sincnoise = Conv sincnoise(1:10000);
Conv RC5noise = Conv RC5noise(1:10000);
Conv_R1noise = Conv_R1noise(1:10000);
% Task 2: Reshaping the sequences to build Eye Diagrams
% With Noise
Conv_sincnoise_reshape = reshape(Conv_sincnoise, SampleFreq*2, N*SampleFreq/20).';
Conv RC5noise reshape = reshape(Conv RC5noise, SampleFreq*2, N*SampleFreq/20).';
Conv R1noise reshape = reshape(Conv R1noise, SampleFreq*2, N*SampleFreq/20).';
% Task 2: Plotting the Eye Diagrams
% With Noise
figure;
plot(0:1/SampleFreq:1.99, Conv sincnoise reshape.', 'b');
title('Eye Diagram - Sinc Pulse with AWGN');
xlabel('Symbol Index');
ylabel('Amplitude');
axis([0 2 -2.4 2.2]);
grid on;
figure;
plot(0:1/SampleFreq:1.99, Conv RC5noise reshape.', 'b');
title('Eye Diagram - Raised Cosine (roll-off=0.5 noisy) with AWGN');
xlabel('Symbol Index');
ylabel('Amplitude');
axis([0 2 -2.4 2.2]);
grid on;
figure;
plot(0:1/SampleFreq:1.99, Conv R1noise reshape.', 'b');
title('Eye Diagram - Raised Cosine (roll-off=1 noisy) with AWGN');
xlabel('Symbol Index');
ylabel('Amplitude');
axis([0 2 -2.4 2.2]);
grid on;
```



































Published with MATLAB® R2017b